




## Roller&Fischer Transformatoren Lager Liste



| Artikel- Nummer         | Artikel- Nummer      | Beschreibung       | Beschreibung 2                 | Kred.-Artikelnr. | Lagerbest and |
|-------------------------|----------------------|--------------------|--------------------------------|------------------|---------------|
| ROFI 25 230+400/230     | 120025230+400/230    | 25VA STEUERTRAF0   | 230V+400V +/- 5% / 230V        | 001-001-0000     | 4             |
| ROFI 40 230+400/230     | 120040230+400/230    | 40VA STEUERTRAF0   | 230V+400V +/- 5% / 230V        | ....             | 6             |
| ROFI 40 230+400/24      | 120040230+400/24     | 40VA STEUERTRAF0   | 230V+400V +/- 5% / 24V         | ....             | 3             |
| ROFI 63 230+400/230     | 120063230+400/230    | 63VA STEUERTRAF0   | 230V+400V +/- 5% / 230V        | ....             | 5             |
| ROFI 63 230+400/24      | 120063230+400/24     | 63VA STEUERTRAF0   | 230V+400V +/- 5% / 24V         | ....             | 4             |
| ROFI 63 230/12          | 120063230/12         | 63VA STEUERTRAF0   | 230V +/- 5% / 12V 50/60Hz      | ....             | 1             |
| ROFI 100 230+400/24     | 120100230+400/24     | 100VA STEUERTRAF0  | 230V+400V +/- 5% / 24V         | ....             | 2             |
| ROFI 100 230/12         | 120100230/12         | 100VA STEUERTRAF0  | 230VAC +/- 5% / 12VAC          | ....             | 1             |
| ROFI 100 230/24         | 120100230/24         | 100VA STEUERTRAF0  | 230VAC +/- 5% / 24VAC          | ....             | 1             |
| ROFI 100 230/42         | 120100230/42         | 100VA STEUERTRAF0  | 230VAC +/- 5% / 42VAC          | ....             | 2             |
| ROFI 100 400/230        | 120100400/230        | 100VA STEUERTRAF0  | 400VAC +/- 5% 7 230VAC         | ....             | 2             |
| ROFI 100 400/24         | 120100400/24         | 100VA STEUERTRAF0  | 400VAC +/- 5% / 24VAC          | ....             | 1             |
| ROFI 100 UNI 210-550/2X | 120100UNI 210-550/2X | 100VA UNI-TRAF0    | prim.210-550V/sek.2x115V       | ....             | 3             |
| ROFI 160230+400/230     | 120160230+400/230    | 160VA STEUERTRAF0  | 230V+400V +/- 5% / 230V        | ....             | 1             |
| ROFI 160230/12          | 120160230/12         | 160VA STEUERTRAF0  | 230VAC +/- 5% / 12VAC          | ....             | 2             |
| ROFI 160400/230         | 120160400/230        | 160VA STEUERTRAF0  | 400VAC +/- 5% / 230VAC         | ....             | 1             |
| ROFI 160UNI 210-550/2X  | 120160UNI 210-550/2X | 160VA UNI-TRAF0    | prim.210-550V/sek.2x115V       | ....             | 5             |
| ROFI 250 230+400/230    | 120250230+400/230    | 250VA STEUERTRAF0  | 230V+400V +/- 5% / 230V        | ....             | 1             |
| ROFI 250 230/24         | 120250230/24         | 250VA STEUERTRAF0  | 230VAC +/- 5% / 24VAC          | ....             | 2             |
| ROFI 250 400/24         | 120250400/24         | 250VA STEUERTRAF0  | 400V +/- 5% / 24V              | ....             | 3             |
| ROFI 315 230+400/230    | 120315230+400/230    | 315VA STEUERTRAF0  | 230V+400V +/- 5% / 230V        | ....             | 1             |
| ROFI 315 230+400/24     | 120315230+400/24     | 315VA STEUERTRAF0  | 230V+400V +/- 5% / 24V         | ....             | 3             |
| ROFI 315 UNI 210-550/2X | 120315UNI 210-550/2X | 315VA UNI-TRAF0    | prim.210-550V/sek.2x115V       | ....             | 1             |
| ROFI 400 230+400/230    | 120400230+400/230    | 400VA STEUERTRAF0  | 230V+400V +/- 5% / 230V        | ....             | 2             |
| ROFI 400 230+400/24     | 120400230+400/24     | 400VA STEUERTRAF0  | 230V+400V +/- 5% / 24V         | ....             | 4             |
| ROFI 400 UNI 210-550/2X | 120400UNI 210-550/2X | 400VA UNI-TRAF0    | prim.210-550V/sek.2x115V       | ....             | 2             |
| ROFI 500 230+400/230    | 120500230+400/230    | 500VA STEUERTRAF0  | 230V+400V +/- 5% / 230V        | ....             | 2             |
| ROFI 500 400/230        | 120500400/230        | 500VA STEUERTRAF0  | 400V +/- 5% / 230V             | 010-012-0000     | 6             |
| ROFI 500 400/230-VDE055 | 120500400/230-VDE055 | 500VA STEUERTRAF0  | 400V +/- 5% / 230V nach VDE055 | ....             | 2             |
| ROFI 500 400/24         | 120500400/24         | 500VA STEUERTRAF0  | 400 V +/- 5% / 24 V            | ....             | 3             |
| ROFI 500 400/24-VDE0551 | 120500400/24-VDE0551 | 500VA STEUERTRAF0  | 400V +/- 5% / 24V nach VDE0551 | 001 009 0019     | 1             |
| ROFI 500 UNI 210-550/2X | 120500UNI 210-550/2X | 500VA UNI-TRAF0    | prim.210-550V/sek.2x115V       | ....             | 3             |
| ROFI 630 UNI 210-550/2X | 120630UNI 210-550/2X | 630VA UNI-TRAF0    | prim.210-550V/sek.2x115V       | ....             | 2             |
| ROFI 800 230+400/230    | 120800230+400/230    | 800VA STEUERTRAF0  | 230V+400V +/- 5% / 230V        | ....             | 1             |
| ROFI 800 230+400/24     | 120800230+400/24     | 800VA STEUERTRAF0  | 230V+400V +/- 5% / 24V         | ....             | 2             |
| ROFI 800 UNI 210-550/2X | 120800UNI 210-550/2X | 800VA UNI-TRAF0    | prim.210-550V/sek.2x115V       | ....             | 1             |
| ROFI 1000 230+400/24    | 121000230+400/24     | 1000VA STEUERTRAF0 | 230V+400V +/- 5% / 24V         | ....             | 3             |
| 12K1,6400/230           | 12K1,6400/230        | 1,6kVA STEUERTRAF0 | 400V +/- 5% / 230V             | ....             | 2             |
| 12K1,6400/24            | 12K1,6400/24         | 1,6kVA STEUERTRAF0 | 400VAC +/- 5% // 24VAC         | ....             | 2             |
| 12K1,6UNI 210-550/2X    | 12K1,6UNI 210-550/2X | 1,6kVA UNITRAFO    | prim.210-550V/sek.2x115V       | ....             | 1             |
| 12RNG 230/24 0,4A       | 12RNG 230/24 0,4A    | Einphas.Netzgerät  | 230V/24VDC 400mA RINGKERN      | RNG 04           | 2             |